

Part #	Discription
MS-SOLARWING350-01	Battery box wing nut
MS-SOLARWING350-02	Battery box
MS-SOLARWING350-03	Battery mounting block
MS-SOLARWING350-04	Battery
MS-SOLARWING350-05	Brake caliper
MS-SOLARWING350-06	Solar panel
MS-SOLARWING350-07	Solar Wing
MS-SOLARWING350-08	Frame
MS-SOLARWING350-09	Flag w/mast
MS-SOLARWING350-10	Controller
MS-SOLARWING350-11	Seat
MS-SOLARWING350-12	Handle bar clamp
MS-SOLARWING350-13	Throttle
MS-SOLARWING350-14	Handle bar
MS-SOLARWING350-15	Brake lever
MS-SOLARWING350-16	Handle grip
MS-SOLARWING350-17	Brake cable
MS-SOLARWING350-18	Steering stem
MS-SOLARWING350-19	Cross over steering short rod
MS-SOLARWING350-20	Heim end
MS-SOLARWING350-21	Cross over steering long rod
MS-SOLARWING350-22	Steering spindle
MS-SOLARWING350-23	Rod sleeve
MS-SOLARWING350-24	Steering spindle sleeve
MS-SOLARWING350-25	Bearing 6001
MS-SOLARWING350-26	Inner front rim
MS-SOLARWING350-27	Outer front rim
MS-SOLARWING350-28	Front tire sleeve
MS-SOLARWING350-29	Tire tube
MS-SOLARWING350-30	Tire
MS-SOLARWING350-31	Charger
MS-SOLARWING350-32	Electrical box
MS-SOLARWING350-33	Charging plug
MS-SOLARWING350-34	Wire loom
MS-SOLARWING350-35	Main harness
MS-SOLARWING350-36	steering stem support
MS-SOLARWING350-37	Brake disc
MS-SOLARWING350-38	Disc hub
MS-SOLARWING350-39	Sporcket
MS-SOLARWING350-40	Inner rear rim for sporcket
MS-SOLARWING350-41	Rear tire sleeve
MS-SOLARWING350-42	Chain cover
MS-SOLARWING350-43	Motor cover
MS-SOLARWING350-44	Switch cover
MS-SOLARWING350-45	Chain
MS-SOLARWING350-46	Chain gard
MS-SOLARWING350-47	Motor

